

Boat.

Beacon.



Installation guide.

SK50 SoluNaute Beacon.

Installation guide

Balise SK50 SoluNaute.

Installation guide.

Package contents.

- 1 beacon
- 1 specific POGO magnetic USB cable
- 1 main charger
- 3 mounting collars

The beacon.

This is a professional beacon of geolocation by satellite network and GSM.

It does not require any activation or maintenance action.

The beacon has a direction as shown in the photo below. The tag "Helvetia" must be facing upwards to guarantee communication capability.

Designed to operate autonomously for two years using an internal lithium battery, your beacon is delivered activated and fully charged.

However, make sure to keep the cable and charger in order to charge it.


Step 1 : Beacon installation.

You can immediately install your beacon on your ship using the collars provided.

Suitable for a marine environment, the beacon must be placed outdoors.

It may be placed in a thin compartment taking care to avoid objects that could interfere: wood, metal, instruments emitting waves.

Railings, stanchion, guard line, pushpit/pulpit, handholds, shroud, masts, supports, bimini, fixed flagpoles, bulwarks or coamings are all potential hanging points.



Step 2 : **Check its operation.**

Your beacon will «search its position» via the GSM network then Satellite if needed and transmit on its position twice a day.

You will be able to check its operation within 12 hours after installation on your ship by connecting to the Konectis website with your username and password.

www.konectis.com

Note : On land, the accuracy of location in GSM mode is of the order of several tens of meters, which is perfectly normal.

Step 3 : **Recharge the beacon.**

Your beacon will run for two years with its initial charge.

You can recharge it using the POGO cable, which has a magnetic keying and charger.

The beacon will be fully charged in 24 hours.

In case of need and for any question :

Do not hesitate to contact the beacon service:

SAVE Group

balise@groupe-save.com

T +33(0)2 35 22 14 29

If necessary, you can find the serial number of the beacon here :



Headquarter

Le Havre

25 quai Lamandé

76600 Le Havre

T +33(0)2 32 92 92 92

www.helvetia.fr



simple. clear. helvetia 
Your Swiss Insurer

Imprimé sur du papier certifié FSC.

**Climatiquement neutre**
Entreprise
ClimatePartner.com/1937-8809-1001